

USB Port Printer List

Brand	Type	Model
HP	Deskjet	640C, 656C, 845C, 920C, 940C, 948C, 960C, 990CXI, 995C, 125C, 1180C, 3320, 3420, 3425, 3535, 3650, 5625, 3745, 3845
	Inkjet	DeskJet5610, DeskJet5650, DeskJet5850, CP1700, Business InkJet 1000
	Laserjet	1200, 2200, 2200D, 2300D, 4600PS, 9000
	Multi-Function Machine	PSC-1350, PSC-1210, PSC-1610, PSC-1650, PSC-2355, OfficeJet 5510, OfficeJet 6110, OfficeJet 6210 Printing function support only
	HostBase (GDI)	LaserJet 1010, 1020, 1022, 1160 Color LaserJet 2600N, 3500, 3550 (APSUSB211 not support) (APSUSB201, APSUSB203 F/W 3.22 or above support) (APSUSB201W F/W 3.25 or above support)
LexMark		Z13, Z33, Z43, Z53, Z25, Z35, Z45, Z615, Z810, Z818, 4039 10R, 5700, Optra Color 45 Optra C710, Optra E, E+, E310, E230, Optra K1220, Optra M410, M412, Optra N, Optra R+, Optra S1250, Optra S1855, Optra SC-1275, Optra SE-3455, OptraT614 Optra W810
	Multi-function Machine	X5150, X7170, X6170, X5270 Printing function support only
Canon		S100SP, S200SP, S300, S330, S400SP, S520, S600, S6300, S750, S450, S4500, S9000, PIXUS 850i, BJC55, BJC85, I850, IP1000, IP3000, IP4000
	Multi-function Machine	MP 110 Printing function support only
EPSON	Stylus	C41UX, C405, C60, C61, C80, C42UX, RX510, C43, C45
	Photo	R310, 720, 810, 820, 830, 830U, 890, 900, 1280, 1290, PM860PT, CC550L, CC570L, CL750, CL760, MC-2000, PM680C, PM-720C, PM-730C, PM-740C, PM740DU, PM-D750, PM-780CS, PM-790PT, PM-800C, PM-800DC, PM-820C, PM-820DC, PM-830C, PM-840C, PM-850PT, PM-860PT, PM-870C, PM-890C, PM-G900, PM-920C, PM-930C, PM-940C, PM-950C, PM-970C, PM-980C, PM-D1000, PM-2200C, PM-3300C, PM-3500C, PM-3700C, PM-4000PX , PM-A850, PM-D750, PM-G700, PM-G800, E-100, E-200, PM-D770, PX-G5000, PX-G920, PX-5500, PM-4000PX, PM-G820, PM-G720

	Laser	PX-V500, PX-V600, PX-V700, PX-G900, 900, 1160, 2200, LP-1200, LP-1300 LP-1400, LP1500C, LP-2000C, LP-2400, LP-2500, LP-6100, LP-7000C, LP-7500, LP-7700, LP-7800, LP-7900, LP-8900, LP-9000B, LP-9000C, LP-9100, LP-9400, LP-9500C, LP-9800C, LP-S5500, LP-9200B, LP-9200C, LP-V500, LP-4600PS, LP-V1000, LP-8800CPS, LP-9800CPL, LP-9200CPL, LP-9100PS3, EPL-6200
	Multi-Function Machine	PM-A850, PM-A900, PM-A870, LP-A700, LP-M5500/F, LP-9200CCS, LP-9800CCS, CC-600PX Printing function support only
Other	GDI Printer	FUJI XEROX Phaser 3121, Samsung ML-1520 (APSUSB211 not support) (APSUSB201, APSUSB203 F/W 3.22 or above support) (APSUSB201W F/W 3.25 or above support)

Parallel Port Printer List

Brand	Type	Model
HP	LaserJet	LaserJet III, LaserJet 4P, 4L, 4V, LaserJet 5L, LaserJet 6P, 6L, LaserJet 1100, 1100A, LaserJet 1200, LaserJet 2100, 2100M, LaserJet 2200, LaserJet 3150, LaserColorJet 8500, LaserJet 1100 series, LaserJet 1300 series, LaserJet 2100 series, LaserJet 3150, LaserJet 4000, LaserJet 5000, LaserJet 5100SE, LaserJet 9000, Color LaserJet 4600 PS
	DeskJet	DeskJet 400, 420, DeskJet 500, DeskJet 550C, 560C, DeskJet 670C, 695C, DeskJet720C, DeskJet 810C, 890C, DeskJet 920C, DeskJet 930C(new), 970CXI, DeskJet 1120C, DeskJet 1125C,
	All in One Officejet	T47, 710
LexMark		4039 10R, 5700, Optra Color 45, Optra C710, Optra E, E+, E310, Optra K1220 Optra M410, M412, Optra N, Optra R+, Optra S1250, S1855, Optra SC-1275 Optra SE-3455, Optra T614, Optra W810, Z53
Canon		BJC-255SP, BJ-330, BJC-600, 620, BJC-2000SP, BJC-4100, BJC- 4300, BJC- 4500, BJC- 4550, BJC-6000, BJC- 6500, BJC-7000, BJC-8200, LBP-720, BJC-740, Bubble Jet S520
EPSON		Stylus Photo 700, 710, 750, Stylus Photo 870, Stylus Photo 1200, 1270 Stylus Photo EX, Stylus Pro XL, Stylus Color 400, 440, 460, 480 Stylus Color 600, 640, 660, Stylus Color 740, Stylus Color 800, 850, 860 Stylus Color 900, Stylus Color 1160, Stylus Color 1500, 1520, Stylus Color 3000 Stylus C60, LQ-100, LQ-300, LQ-550, 570+, LQ-1070C+, LQ-2070, 2170C EPL-N2000, N2010, EPL-5500, 5700, 5800
Fujitsu		10V, 14V, DL-700, DL-3800
IBM		5577, 4039 , 16L, Infor Printer 20, InfoPrint 32
NEC		P2200, P3200, P5300, P6300, P7300

Other Printer	Brother HL-1260, CD T120, Citizen GSX-230, Futek 84+, OKI ML-391 OKIdata OL-400, Olivetti JP450, Pannsonic 2023, Panasonic KX-P1624 Printtec PR856C, Star NX-2420, Tektronix Phraser 350, Kyocera FS-1000 Kyocera mita FS-1000+
----------------------	--

Unsupported printer		
Canon		CAPT printer, I80, I860, I445, I450, IP2000, IP5000, MP390, MP730, MP750
Epson		EPL-6200L , Aculaser C900
HP		Laser Jet 1000 serial (DGI printer), Office Jet serial (multi-function machine), 2500C, 2410Xi, 5000, 6210, OJ6110, OJG55, DJ882C, DJ3320, DJ2200, LJ3100, LJ200
LexMark		Z23, Z54, Z515, Z605, Z615, Z700, E210, E232, X6170, X7170
Samsung		ML-1710